




Installation Manual for SLC1 Solar Street Light



Step 2: Use a wrench to loosen the screws securing the lamp pole pressure plate.



Step 3: Insert the lamp into the lamp pole with a diameter of 40 – 60.



Step 4: After adjusting the lamp angle, install the lamp pole pressure plate and tighten it with four M8 screws.